

# Hold-Down Brackets Installation Instructions

1. Set 960 series SaniPottie® portable toilet in desired location, providing clearance for lid and seat in "up" position, and clearance at the sides to unlatch and remove top tank.
2. With side clasps unlatched, place hold-down brackets (with mounting holes facing out) under the lower tank and align with grooves (see illustration).
3. Mark bracket mounting holes.
4. Remove toilet. Fasten brackets to floor or deck with screws provided.
5. Set SaniPottie toilet between brackets and latch in place.



**SeaLand**<sup>®</sup>  
by Dometic GROUP

© Dometic Corporation  
600344398

Dometic Corporation  
13128 State Rt 226  
PO Box 38  
Big Prairie, OH 44611  
1-800-321-9886